

# R1550

## WOOD BOOSTER™ Repair Adhesive Kit

### 1. PRODUCT NAME

ROBERTS® R1550 WOOD BOOSTER™ Repair Adhesive Kit

### 2. MANUFACTURER

**Roberts Company Canada, Ltd.**  
34 Hansen Road South  
Brampton, ON L6W 3H4  
(866) 435-8665 / (905) 791-4444

### 3. DESCRIPTION

ROBERTS® WOOD BOOSTER Repair Adhesive Kit is formulated to repair loose areas or hollow spots under glue-down engineered wood flooring. This formula offers ease of use and low VOC: 5 g/L.

#### Kit Includes

- Wood Booster repair adhesive (946 mL / 1 U.S. quart)
- Applicator syringe (1) with metal tips (2)
- Drill bits (2)
- Dowels (8) and dowel punch (1)

#### Features and Benefits

- Works instantly – floor can be walked on immediately
- Saves money on costly replacements
- Enviro-Friendly – solvent-free
- VOC 5 g/L

#### Uses

For filling hollow spots due to too little adhesive being used, old adhesive crystallizing due to the natural movement of the wood or slight dips in the substrate beneath engineered wood floors.

#### Limitations

- Use only with glue-down engineered wood floors. Do not use this product with solid wood, bamboo or any floating floor.
- Prior to use, ensure substrate, flooring material and adhesive are fully acclimated at the same temperature and humidity level expected during normal use (18–35°C / 65–95°F with a relative humidity of no greater than 65%). Large temperature or humidity increases or decreases can affect the flooring and performance of the installation.
- Ensure adequate ventilation during application.
- Ensure original flooring adhesive is completely cured before attempting to repair installation with the Wood Booster Injection Repair Kit.
- ROBERTS R1550 adhesive is thin and may drip from the syringe even when pressure is not applied.
- In large areas some cupping may occur, but will dissipate after several days.
- If the original adhesive used for installation was not ROBERTS®, test a sample area for compatibility.
- Refer to Safety Data Sheet, [www.robertsconsolidated.com](http://www.robertsconsolidated.com), industry standards, and manufacturer's guidelines and specific recommendations prior to installation for additional information.

### 4. TECHNICAL DATA

<b>Product Type:</b>	Rubber Latex
<b>Color:</b>	White
<b>Odor:</b>	Mild
<b>VOC:</b>	5 g/L
<b>Shelf Life:</b>	1 year in unopened container; protect from freezing
<b>Storage:</b>	Store in a cool, dry place.

### 5. INSTRUCTIONS

- 1) Place releasable blue tape around loose/ hollow area(s) to mark them.  
Note: It is best to repair all areas at once to prevent adhesive from drying in the syringe. In large areas some cupping may occur, but will dissipate after several days.
- 2) In the areas outlined with blue tape, drill hole(s) with the 2 mm (3/32 in.) drill bit provided. For areas 60 cm (2 ft.) or larger, drill a hole on each side of the loose/hollow spot. The larger the area, the more drill holes required.
- 3) Stir adhesive. Attach one of the metal tips onto the syringe. To fill syringe, separate plastic plunger from tube and pour adhesive into the large open end of the tube, or transfer adhesive to a container and draw it up into syringe.
- 4) Place syringe tip in the drilled hole and inject adhesive until back pressure is felt, or for multiple hole areas inject until adhesive comes out another hole. (Do not weigh down floor; allow adhesive to level itself naturally).
- 5) Plug each hole with one of the dowels provided, to keep the adhesive secured under the floor. (Note: The dowels will be slightly larger than the holes and it will be necessary to taper them with a knife or sand paper.) When in place, cut each dowel even with the flooring, then use the dowel punch to lower it just below the surface. Once all dowels are placed, the adhesive repair is complete and the floor may be walked on immediately.

*After application:* Use a wood filler of matching color to fill to the surface of the flooring.



#### Clean-up

Clean up excess adhesive with a clean white cloth, dampened with soap and water. Dry adhesive can be cleaned with mineral spirits or safety solvent. Wash out syringe and applicator tip prior to storage.

#### 6. AVAILABILITY

##### Packaging

WOOD BOOSTER Repair Adhesive Kit	R1550-KC	075378115120
-------------------------------------	----------	--------------

#### 7. WARRANTY

ROBERTS warrants that this product will be free from manufacturing defects for 12 months from the date of manufacture, when applied in accordance with ROBERTS' instructions and industry standards. ROBERTS' sole liability is to either supply new product or refund the original purchase price. **This limited warranty excludes all other express warranties including the warranties of merchantability for a particular use or purpose.** Any implied warranties arising by operation of law are limited to one year. ROBERTS will not be liable for any incidental or consequential damages.

Visit [www.robertsconsolidated.com](http://www.robertsconsolidated.com) for full warranty details.

#### 8. MAINTENANCE

Not applicable.

#### 9. TECHNICAL SERVICES

For technical assistance or installation questions not covered in this document, please contact our Technical Services Department at (905) 791-4444 or visit [robertsconsolidated.com](http://robertsconsolidated.com).

#### 10. FILING SYSTEM

Division 9



ROBERTS® and the e® logo are registered trademarks of Roberts Consolidated Industries, Inc. • Q.E.P.® is a registered trademark of Q.E.P. Co., Inc.

11187