

# Peel and Stick Carpet Tack Strip (3-Pk)

20-1450



**EASY TO INSTALL**  
Simply peel and stick on any subfloor type

**DURABLE**  
Holds up to standard power stretching pressure

**GRIPS INSTANTLY**  
Is immediately ready for stretching



**FOR INSTALLING CARPET**  
No anchor nails required

Scan here for  
PRODUCT  
INFORMATION



The ROBERTS® Smooth Edge Peel and Stick Tack Strips grip instantly to the subfloor to make carpet installation easy. The strong initial grab allows for immediate stretching and holds up to standard power stretching. Simply peel off the adhesive backing, point the pins toward the wall and stick to the subfloor approximately 1/4" from the wall. Stretch carpet as usual.