

# 4" Floor and Wall Scraper & Stripper

10-194

10-294

## INSTRUCTIONS FOR USE

- Make sure the blade is clean and free of debris / adhesive after each use
- Use care when using or storing scraper as it has a sharp blade
- Manufacturer recommends reversing blade when not in use, so sharp blade is not exposed
- If blade displays any rust, cracks, or chips in metal, replace blade immediately

### REPLACEMENT BLADES

Use ROBERTS 10-442-10  
4" Floor & Wall Scraper  
Replacement Blades,  
sold separately.

